Caution: Turn off Power

1. Install in accordance with local electrical codes.
2. Thread lamp holder(s) into cover coating threads with sealing compound (not included).
3. Wire the lamp holder(s) to the supply lines in the box, white to white (neutral) and black to black (hot).
4. Use Par 38 type flood or spot lights, Max 120 Watts.
5. Close all unused holes with closure plugs.
6. Seal all openings to comply with wet location installation.
7. Aim lamp holder(s) to desired angle and tighten nut(s) on ball joint(s).
8. Use a caulking compound to provide a water tight seal between the luminiare and the mounting surface.

Precaución: Interrumpa el suministro eléctrico

1. Instale de acuerdo con la normativa de electricidad local.
2. Introduzca el o los portalámparas en la cubierta revistiendo los hilos con compuesto sellador (no se incluye).
3. Cablee el o los portalámparas hacia las líneas de suministro en la caja de tomacorriente, blanco a blanco (neutro) y negro a negro (activo).
4. Utilice el reflector o luces de reflector tipo 38 de 120 vatios como máximo.
5. Tape todos los agujeros no utilizados con los tapones de cierre.
6. Selle todas las aberturas para cumplir con la instalación en lugares húmedos.
7. Dirija el o los portalámparas al ángulo deseado y apriete la o las tuercas de seguridad en la o las juntas de rótula.
8. Use un compuesto de calafateo para sellar de forma impermeable la luminaria a la superficie de montaje.